



NodeJS and Serial Data

Professor:

Bladimir Bacca Cortes Ph.D.


Bladimir.bacca@correounivalle.edu.co

Grupo de Investigación en Percepción y Sistemas Inteligentes.



Contents

- Serialport package installation.
- Proteus test platform installation.
- API description.
- Serial port events.
- Listing serial ports in the system.
- Reading data from serial port
- Writing data from serial port
- Parsers on serial port.




Serialport Package Installation

- Serialport library needs to be installed using npm.

Prompt> npm install serialport

- Remember:
 - If you install a module globally, it will not be able to be imported by `require()`.
 - g parameter defines a global installation.
 - Otherwise, in the folder application will appear a subdirectory called **node_modules**, and in that directory it will install all the necessary assets for the **serialport** library.
 - Docs: <https://serialport.io/docs/10.x.x/>



```
Administrador: C:\Windows\system32\cmd.exe

C:\Users\BladimirBaccaCortes>npm install serialport -g


> @serialport/bindings@2.0.8 install C:\Users\BladimirBaccaCortes\AppData\Roaming\npm\node_modules\serialport\node_modules\@serialport\bindings
> prebuild-install --tag-prefix @serialport/bindings@ || node-gyp rebuild

+ serialport@7.1.5
added 78 packages from 45 contributors in 13.118s

C:\Users\BladimirBaccaCortes>
```



Proteus Test Platform Installation

- **Problem:** Lot of laptops do not have serial ports, and for testing point of view is more comfortable not using hardware attached to serial ports.
- **Solution:** Serial Terminal – Proteus + COMPIM + **Virtual serial ports.**
- **Basic steps – Virtual serial ports:**
 - Go to <https://www.virtual-serial-port.org/> and download the Virtual Serial Port Driver
 - Execute it.
 - Add a pair of serial ports.




Proteus Test Platform Installation

- **Problem:** Lot of laptops do not have serial ports, and for testing point of view is more comfortable not using hardware attached to serial ports.
- **Solution:** Serial Terminal – **Proteus** + **COMPIM** + Virtual serial ports.
- **Basic steps – COMPIM:**
 - Load the **nodeJSSerialPort** Proteus project.
 - Edit the COMPIM component.
 - Connect it to the COM4 using 9600-N-8-No parity configuration.




Proteus Test Platform Installation

- **Problem:** Lot of laptops do not have serial ports, and for testing point of view is more comfortable not using hardware attached to serial ports.
- **Solution:** [Serial Terminal](#) – Proteus + COMPIIM + Virtual serial ports.
- **Basic steps – Hyperterminal:**
 - Download Hyperterminal or any other Terminal software to connect to serial ports.
 - Execute it.
 - Configure it in order to connect to the COM2 serial port using 9600-N-8-No parity parameters.



Proteus Test Platform Installation

- **Problem:** Lot of laptops do not have serial ports, and for testing point of view is more comfortable not using hardware attached to serial ports.
- **Solution:** Serial Terminal – Proteus + COMPIIM + Virtual serial ports.
- **Final test:**
 - Load the nodeJSSerialPort Proteus project.
 - Execute it.
 - The temperature of 4 LM35 will be shown in the Proteus virtual terminal, and in the Hyperterminal software.



API Description

- **Stream interface**

const SerialPort = **require**('@serialport/stream')

const SerialPort = **require**('serialport')

- **Constructor and options**

new SerialPort(path [, openOptions] [, openCallback])

[**autoOpen=true**] Automatically opens the port on `nextTick`.

[**baudRate=9600**] The baud rate of the port to be opened.

[**dataBits=8**] Must be one of these: 8, 7, 6, or 5.

[**highWaterMark=65536**] The size of the read and write buffers.

[**lock=true**] Prevent other processes from opening the port.

[**stopBits=1**] Must be one of these: 1 or 2.

[**parity=none**] Must be one of these: 'none', 'even', 'mark', 'odd', 'space'.

[**rtscts=false**] flow control setting

[**xon=false**] flow control setting

[**xoff=false**] flow control setting

[**xany=false**] flow control setting

- **Serial port properties**

serialport.**baudRate**: number

serialport.**isOpen**: Boolean

serialport.**path**: string

serialport.**binding**: Binding

- **Events**

- On open
- On error
- On close
- On data
- On drain (re-write information because of errors).

API Description

- **Standard methods**

serialport.**open**((() => {}): void

serialport.**update**(options: updateOptions, callback?: err => {}): void

serialport.**write**(data: string| Buffer| Array<number>, encoding?: string, callback?: error => {}): Boolean

serialport.**read**(size?: number): string| Buffer| null

serialport.**close**(callback?: error => {}): void

serialport.**set**(options: setOptions, callback?: error => {}): void

serialport.**get**(callback: (error, data: ModemStatus) => {}): void

serialport.**flush**(callback? error => {}):void

API Description

- **Standard Methods**

serialport.**drain**(callback? error => {}):void

serialport.**pause**(): this

serialport.**resume**(): this

- **Serial port Parsers**

- **ByteLength**: Emit data every number of bytes.
- **CCTalk**: A transform stream that emits ccTalk packets as they are received.
- **Delimiter**: A transform stream that emits data each time a byte sequence is received. To use the Delimiter parser, provide a delimiter as a string, buffer, or array of bytes.
- **Readline**: A transform stream that emits data after a newline delimiter is received. To use the Readline parser, provide a delimiter (defaults to \n).
- **Ready**: A transform stream that waits for a sequence of "ready" bytes before emitting a ready event and emitting data events
- **Regex**: A transform stream that uses a regular expression to split the incoming text upon.

Serial Port Events

- The **serialport** library, like most node.js libraries, is **event-based**.
- This means that when the **program** is **running**, the **operating system** and the **user's** actions will **generate events** and the **program** will **provide functions** to **deal** with those **events** called callback functions.

- **Events description:**

- **Open:** The open event happens when the port is opened and ready for writing. This happens if you have the constructor open immediately.

- **Close:** The close event's is emitted when the port is closed. In the case of a disconnect it will be called with a Disconnect Error object (`err.disconnected == true`).
- **Error:** The error provides an error object whenever there is an unhandled error. You can usually handle an error with a callback to the method that produced it.
- **Data:** Listening for the data event puts the port in flowing mode. Data is emitted as soon as it's received. Data is a Buffer object with any amount of data in it.
- **Drain:** The drain event is emitted when it is performant to write again if a `write()` call has returned false.

`myPort.on('open', showPortOpen);`

`myPort.on('data', sendSerialData);`

`myPort.on('close', showPortClose);`

`myPort.on('error', showError);`

`function showPortOpen() {`

`console.log('port open. Data rate: ' + myPort.options.baudRate); }`

`function sendSerialData(data) {`

`console.log(data); }`

`function showPortClose() {`


`console.log('port closed.');`

`function showError(error) {`

`console.log('Serial port error: ' + error); }`

Writing Data to Serial Port

- The **process** of **using** the **serialport** library will be the same every time:
 - Initialize the serialport library
 - open the serial port
 - Set up the callback functions and let them do the rest
- **Remember:**
 - The properties such as stop bits, parity, data size have default values as follows:
 - *Stop bits: 1*
 - *Parity: none*
 - *Data size: 8*
 - You must **configure** the **communication speed**.
- **Note:** The Program **Won't Stop!**. When you run this program now, it won't automatically stop and return to the command line. **To stop it**, you'll **need** to type **control-C** in the **terminal window** to **stop it**.
- The new **instance** of **Serialport** created a software object that **listens** for **events** from the **serial port**. Any node.js script that creates an event listener like this will run until you explicitly stop it.
- Open folder **1-WrittingReadingData**, then run **writeSerialPort.js**.



The screenshot shows a code editor with a file named `writeSerialPort.js`. The code defines a `SerialPort` object for COM4 at 9600 baud and sets up `onOpen` and `onWrite` event listeners. The `onOpen` function logs an error if the port fails to open. The `onWrite` function logs an error if writing fails. Below the code editor, a terminal window titled "COM4-Connection - HyperTerminal" is open, displaying the message "Hello Serial Port Terminal !_". The terminal's status bar shows "Connected 00:00:23" and various settings like "Auto detect", "9600 8-N-1", "SCROLL", "CAPS", "NUM", "Capture", and "Print echo". At the bottom, a command prompt shows the command `node writeSerialPort.js` being executed in the directory `i:\00-Univalle-Pendientes\Curso-Interfaces\NodeJS\10-NodeJSandSerialData\2-WritingReadingData`.

```
JS writeSerialPort.js x
JS writeSerialPort.js onWrite
1  var SerialPort = require('serialport');
2
3  var mySPport = new SerialPort('COM4', {baudRate: 9600});
4
5  //////////////////////////////////////////////////
6  function onOpen (error)
7  {
8      if (error)
9      {
10         return console.log('Error openning Serial Port: '+error.message);
11     }
12 }
13
14 //////////////////////////////////////////////////
15
16 function onWrite(error)
17 {
18     if (error)
19     {
20         return console.log('Error writing Serial Port: '+error.message);
21     }
22 }
23
```

PROBLEMS OUTPUT DEBUG CONSOLE TERMINAL 1: node

COM4-Connection - HyperTerminal

File Edit View Call Transfer Help

Hello Serial Port Terminal !_


Connected 00:00:23 Auto detect 9600 8-N-1 SCROLL CAPS NUM Capture Print echo

he Node.js process with a non-zero exit code.

i:\00-Univalle-Pendientes\Curso-Interfaces\NodeJS\10-NodeJSandSerialData\2-WritingReadingData>node writeSerialPort.js

Nearpod Activity

- Please go to the Nearpod link shared in the chat.
- Fulfil the Nearpod activity.
- Analyze the results with your teacher.



Parsers on Serial Port

- **Parsers:** Transform streams that process incoming data.
- To use the parsers, you must create them and then pipe the Serialport to the parser.
- Be careful to only write to the SerialPort object and not the parser.

- **Types:**

- **ByteLength Parser:** Emit data every number of bytes. A transform stream that emits data as a buffer after a specific number of bytes are received.
- Arguments: *options.length*: number the number of bytes to be emitted on each data event

```
new ByteLength(options)
```

- **Delimiter Parser:** A transform stream that emits data each time a byte sequence is received. To use the Delimiter parser, provide a delimiter as a string, buffer, or array of bytes

```
new Delimiter(options: { delimiter: string | Buffer |  
number[] })
```

- Arguments: *options.delimiter*: string| Buffer| number[] The delimiter in which to split incoming data.
- **InterByteTimeout Parser:** Emits data if there is a pause between packets for the specified amount of time. A transform stream that emits data as a buffer after not receiving any bytes for the specified amount of time.

```
new InterByteTimeout(options)
```

- Arguments: *options.interval*: number the period of silence in milliseconds after which data is emitted.
- *options.maxBufferSize*: number the maximum number of bytes after which data will be emitted. Defaults to 65536.

Parsers on Serial Port

- **Readline Parser**: A transform stream that emits data after a newline delimiter is received. To use the Readline parser, provide a delimiter (defaults to `\n`). Data is emitted as string controllable by the encoding option (defaults to `utf8`).

`new Readline(options?)`

- Arguments: *options.delimiter?*: string delimiter to use
- *options.encoding?*: string text encoding for the stream
- **Ready Parser**: A transform stream that waits for a sequence of "ready" bytes before emitting a ready event and emitting data events. To use the Ready parser provide a byte start sequence.

`new Ready(options)`

- Arguments: *options.delimiter?*: string delimiter to use to detect the input is ready

- **Regex Parser**: A transform stream that uses a regular expression to split the incoming text upon. To use the Regex parser provide a regular expression to split the incoming text upon.

`new Regex(options)`

- Arguments: *options.regex*: RegExp the regular expression to use to split incoming text
- *options.encoding?*: string text encoding for the stream
- **(Serial Line Internet Protocol) Slip Encoder Parser**: A transform stream that emits SLIP-encoded data for each incoming packet.

`new SlipEncoder(options)`


- Arguments: *options.bluetoothQuirk*: boolean Adds another `0xC0` character at the beginning if the `bluetoothQuirk` option is truthy

- ```
mySerialPort.on('open', onOpen);

mySerialPort.open();

var myParserSP = mySerialPort.pipe(new ReadlineParser({delimiter: '\r\n'}));

myParserSP.on('data', function(data){
 console.log('Data received: ' + data);
});
```



Universidad  
del Valle




# Reading Raw Data from Serial Port

- Reading encapsulated data on serial port: **Pattern detection**.
- To do that, **parsers** must be used: **Delimiter parser**.
- Then, **Buffers** must be used to encode raw data.

```
var myParserSP = mySerialPort.pipe(new DelimiterParser({delimiter: '~'}));

myParserSP.on('data', function(data){
 console.log('Data Frame Received: ', data);
 console.log('Temperature Ch0: ', data.readFloatLE(0));
 console.log('Temperature Ch1: ', data.readFloatLE(4));
 console.log('Temperature Ch2: ', data.readFloatLE(8));
 console.log('Temperature Ch3: ', data.readFloatLE(12));
});
```

- Open **nodeJSSerialPort-V2.pdsprj** Proteus project, then run it.
- Open **1-WritingReadingData**, then run **readFloatSerialPort.js**.




```
PROBLEMS OUTPUT DEBUG CONSOLE TERMINAL

Temperature Ch3: 15
Data Frame Received: <Buffer 00 00 04 42 00 00 a0 41 00 00 98 41 00 00 70 41>
Temperature Ch0: 33
Temperature Ch1: 20
Temperature Ch2: 19
Temperature Ch3: 15
Data Frame Received: <Buffer 00 00 04 42 00 00 a0 41 00 00 98 41 00 00 70 41>
Temperature Ch0: 33
Temperature Ch1: 20
Temperature Ch2: 19
Temperature Ch3: 15
Data Frame Received: <Buffer 00 00 04 42 00 00 a0 41 00 00 98 41 00 00 70 41>
Temperature Ch0: 33
Temperature Ch1: 20
Temperature Ch2: 19
Temperature Ch3: 15
```

# Nearpod Activity

- Please go to the Nearpod link shared in the chat.
- Fulfil the Nearpod activity.
- Analyze the results with your teacher.



# Questions?

